


Transmitter Side



Audio RF Signal

Metadata

Audio input level
 Battery remaining capacity
 Low-cut filter frequency
 Attenuator level
 Transmitter name
 etc.

Wireless Remote Control

TX FREQUENCY setting
 TX RF POWER setting
 TX ATT LEVEL setting
 TX LCF FREQUENCY setting
 TX POWER MODE setting
 +48 V DC power supply setting (DWT-P01 only)

Receiver Side

